



City of Seattle
 Department of Construction and Inspections
 Applicant Services Center
 700 Fifth Ave, Suite 2000, P.O. Box 34019
 Seattle, WA 98124-4019
 www.seattle.gov/sdci

Phone: 206-684-8850

City of Seattle Pilot Infiltration Test (PIT) Checklist

Call before you dig – Utility Locates 811

Project Address: 6719 42nd Ave South Date: 6/23/2022

Permit Number: _____

Other Project Information: _____

This Infiltration Test was performed by:

Company Name: The Concept Group Primary Contact Name: Anna Nguyen

Phone Number: (206) 446-1291 Email Address: hello@ConceptBusinessGroup.com

Include site map or drainage control plan, with test locations clearly marked.

The intent of this checklist is to provide a summary of stormwater BMP infiltration testing requirements associated with the Pilot Infiltration Test (PIT). All projects and associated plans are also subject to the minimum requirements outlined in the City of Seattle Stormwater Manual and SMC Chapters 22.800 – 22.808, as well as the specific subsurface investigation and infiltration testing requirements outlined in Volume 3, Chapter 3 and Appendix D of the 2021 City of Seattle Stormwater Manual. See also Appendix C for site constraints that preclude infiltration facility feasibility (such as site slope > 8%).

This checklist does not preclude the use of professional judgment to evaluate and manage risk associated with design, construction, and operation of infiltration BMPs. Justification for testing procedures that deviate from the minimum investigation requirements specified in Appendix D shall be documented in a stamped and signed letter from a State of Washington licensed professional (licensed professional engineer, engineering geologist, geologist, or hydrogeologist) who has experience in infiltration and groundwater testing and infiltration facility design.

Before you start call Utility Locates 811 to request locates of utilities at your site.

SMALL PILOT INFILTRATION TEST (SMALL PIT) AND LARGE PILOT INFILTRATION TEST (LARGE PIT):

Note: The test methods outlined below may be modified due to site conditions if recommended by the licensed professional and the reasoning is documented in the testing report.

1. Indicate type of test:

- Small PIT
- Large PIT

2. Date and time of tests: 6/23/2022 @ 8 am

3. Is the infiltration test within the footprint of the proposed infiltration facility? (Yes/No) Yes

4. If “no,” is testing being conducted within 50 feet of the proposed infiltration facility? (Yes/No) Yes
 Explain why: Location of facility is still unknown; but BMP should be within 50 ft of test pit.

5. What is the total proposed impervious area (does not include permeable pavement surfaces) to be infiltrated on the site? TBD ft²
(Note: acceptance testing is required if testing was performed greater than 50 feet from the proposed infiltration facility, and greater than 5,000 ft² infiltrated on the site [see City of Seattle Stormwater Manual, Volume 3, Section 3.2].)
6. Dig an infiltration test pit
7. Test pit excavated to bottom elevation of the proposed infiltration facility (Yes / No)
(See City of Seattle Stormwater Manual, Appendix D for additional details.)
8. Test pit surface dimensions (ft): Length: 4.0 Width: 3.0 Depth: 3.0
9. Test pit bottom dimensions (ft): Length: 4.0 Width: 3.0
10. Test pit bottom area (ft²): 12.0
11. Small PIT only: Is the surface area of the test pit bottom at least 12 ft²? (Yes / No)
12. Large PIT only: Is the surface area of the test pit bottom at least at least 32 ft²? (Yes / No)
 a. If "no," indicate why: _____
13. Large PIT only: The test pit bottom area should be as close to the bottom area of the proposed infiltration facility as is feasible.
 a. Bottom area of proposed infiltration facility: _____ ft²
 b. Bottom area of test pit: _____ ft²
14. Identify device used to measure water level in test pit:
 Pressure transducer (recommended for areas with slow draining soils), or
 Vertical rod (min 5 ft long, 1/2-inch increments, placed in center of pit)
15. Identify method of delivering water to the bottom of the test pit (e.g., rigid pipe with a splash plate):
rigid pipe with a splash plate
(The method of delivery must reduce erosion in the test pit that could cause clogging of the infiltration receptor)

16. **Testing Procedure:**

- a. **Pre-soak period:** Add water to maintain water level at least 12 inches above the bottom of the test pit for at least 6 hours. Record the time and depth of water hourly in the table below.

Time of Measurement (hh:mm)	Depth of Water (inches)
8:00 am	12
9:00 am	12
10:00 am	12
11:00 am	12
noon	12
1:00 pm	12
2:00 pm	12
3:00 pm	12
4:00 pm	12

- b. **Steady-state period:** The steady-state data is used to establish the measured infiltration rate (see step 17)
- i. Add water to the test pit at a rate that will maintain a depth of 12 inches above the bottom of the test pit for 1 full hour. During this hour, record the time, depth of water, cumulative volume, and instantaneous flow rate every 15-minutes in the table below.
 - ii. Calculate the infiltration rate for each 15-minute interval. First convert the flow rate to in³/hr and the test pit bottom area (recorded in step 10) into in². Divide the flow rate by the bottom area and record the result in the table below.

infiltration rate calculated from the steady-state data):

- a. Steady-state measured infiltration rate: Provide the lowest infiltration rate from steady-state table above: water level remained stagnant _____ in/hr
- b. Selected "Measured Infiltration Rate" _____ infiltration infeasible _____ in/hr
(Include an explanation if the selected rate deviates from the steady-state rate in step 16a.)
during presoak period, water level remained steady _____
- c. If the lowest measured infiltration rate is less than the minimum rate associated with an infiltration BMP, that BMP cannot be used.
- d. If the measured infiltration rate is less than all minimum infiltration rates for infiltration BMPs (see Table 1 in the Reference Tables at the end of this document), no further investigation is required.

18. Calculate "Design Infiltration Rate": The design infiltration rate shall be calculated by applying the appropriate correction factor to the above measured infiltration rate (see the City of Seattle Stormwater Manual, Appendix D, Section D-4).

- a. Select a correction factor.
- b. Calculate the Design Infiltration Rate below.

<input checked="" type="checkbox"/> Design infiltration rate = _____ x _____ = infiltration infeasible _____ in/hr <div style="text-align: center; margin-top: -10px;"> Measured infiltration rate (in/hr) Correction Factor* </div>
--

*A Correction Factor of 0.5 must be used for all projects unless a lower value is warranted by site conditions, as recommended and documented by a licensed professional, and shall not be less than 0.2. See Appendix D, Section D-4.2.

19. Supporting Documents and Additional Analysis Required:

- a. Include a report for the Small and Large PIT that includes documentation of the testing procedure (including this checklist and any supporting documentation), analysis, and results to assess infiltration feasibility, and an explanation of the correction factor used to determine the design infiltration rate. In addition, include the following information.
- b. One or more of the following analysis/reports will be required. See Table 3.1 and Table 3.2 in Volume 3, Section 3.2 of the City of Seattle Stormwater Manual. Indicate which analysis/reports are required below and include them in the report.
 - Standard Subsurface Investigation Report (Appendix D, Section D-2.4)
 - Comprehensive Subsurface Investigation Report (Appendix D, Section D-2.5)
 - Groundwater Monitoring Report (Appendix D, Section D-5)
 - Characterization of Infiltration Receptor (Appendix D, Section D-6)
 - Groundwater Mounding and Seepage Analysis (Appendix D, Section D-7)

SIGNATURES ARE REQUIRED

The Small and Large PIT report shall be prepared by a licensed professional.

I certify that I have followed the procedures outlined in this document to determine the infiltration BMP infiltration rate.

Infiltration Test performed by:

Print Name Anna Nguyen

Signature  Date 6/23/2022

Professional Stamp:



REFERENCE TABLES

Table 1. Minimum Measured Infiltration Rates (Taken from the 2021 City of Seattle Stormwater Manual, Vol. 3, Section 3.2 – Table 3.3)

Infiltration BMP	Minimum Measured Infiltration Rate for On-site List Approach (in/hr)	Minimum Allowed Measured Infiltration Rate for Meeting Flow Control, Water Quality Treatment, and On-site Performance Standards (in/hr)
Infiltration Trenches	5	5
Drywells	5	5
Infiltrating Bioretention without underdrain	0.6	0.6
Infiltrating Bioretention with underdrain	0.3	No minimum
Rain Gardens	0.3	Not applicable (only for On-site List Approach)
Permeable Pavement Facility	0.3	0.3 ^b
Permeable Pavement Surface	0.3 ^a	No minimum
Sidewalk/Trail Compost-Amended Strip	0.3 ^a	No minimum
Perforated Stub-out Connections	0.3	Not applicable (only for On-site List Approach)
Infiltration Basins	Not applicable	0.6
Infiltration Chambers/Vaults	Not applicable	0.6

^a Infiltration testing not required, only necessary to prove infeasibility.

^b No minimum infiltration rate if underdrain is installed.